

USB Serial Converter

Quick Installation

On Windows® 2000 / Windows® XP / Windows® Vista / Windows® 7 / Windows® 8 / Windows® 8.1

Note: DO NOT connect the USB Serial Converter to your computer before completing the driver installation.

1. Insert the provided CD into your CD-ROM drive. Run the **Setup** file under **E:\Driver** where E: is your CD-ROM drive letter. When the welcome screen appears, click **Next**.
2. Click **Finish** to complete the installation.
3. Once the installation is done, connect the converter to a free USB port on your computer.

On Mac OS® X

1. Insert the provided driver CD into your CD-ROM drive. Double-click the CD icon on the desktop and navigate to the directory of **\Driver\MacX**. Copy and then paste the **PL2303...dmg** file to the desktop.
2. Double-click the dmg file on the desktop to extract the file. Then double-click the **PL2303...** file that is extracted.
3. When the welcome screen appears, click **Continue**.
4. Select a destination disk to install the driver and click **Continue**.
5. Click **Install**.
6. When the **Authenticate** screen appears, enter your password in the provided field and click **OK**.
7. Click **Continue Installation**.
8. Click **Restart** to finish installing the driver and reboot your Mac.
9. Connect the converter to a free USB port on your Mac.

Connecting Serial Device

Now you can connect your RS-232 device to the converter. If prompted to install the driver for your serial device, follow the manual that comes with your serial device to complete the installation.

This Quick Installation Guide describes only the basic instructions on installation. For more information, please refer to the User's Manual on the provided CD-ROM.
--